

**Why do we need adapters?**

Between-series adapters offer reliable transitions between equipment-mounted connectors and devices under test. Bulkhead mounted versions are useful when subminiature connectors are used inside equipment for space saving, but a larger interface is desired for input / output of signals.

Adapters are available between SMB and SMC series, and from BNC, N, or TNC to a wide variety of subminiature plugs and jacks.